


Model: WBG6813-TE
Service code:WBG6813TE251124
Handle and controls

WB GT 6813-TE

r.v. 2026




Part1 Handle and controls Spare parts list		
No.	ID Zboží	Název
1	0102006016	Bolt - M6*16
2	GT68WA19000/44	Big handle cover
3	GT68WA17000B1	Swing blade clutch cable
4	34810001	Turn controlling switch
5	3481000201	Steering button pad
6	0104006035	Screw - M6*35
7	0301006000	Flat washer - φ6
8	3481000301	Steering handle board
9	0202005000	Lock nut - M5
10	3481000602	Steering handle spring
11	0202006000	Lock nut - M6
12	GT68WA31000	VE shock absorber φ20*10 M6*16
13	0501002016	Cotter pin - φ2*16
14	0103006035	Bolt - M6*35
15	3481000701	Speed control regulating pad
16	34810008	Speed regulating switch
17	3481000902	Speed regulating switch mounting base
18	3481001102	Speed regulating handle base
19	1301012000	Check ring - φ12
20	0301016000	Flat washer - φ16
21	GM56A060000080	Sliding bearing
22	0101006055	Bolt - M6*55
23	3481001502	Limit shaft
24	34810018	Spring for speed regulating handle
25	2101008030	Handle ball - M8
26	3481001901	Speed regulating handle
27	GT68WA32000B1/01	Blade clutch handle
28	0202008000	Lock nut - M8
29	0301008000	Flat washer - φ8
30	GT68WA33000B1/01	Blade clutch lock block
31	GT68WA28000	Lock nylon sleeve
32	GT68WA34000/02	Blade clutch spring
33	1001012000	Circlip - φ12
34	6001-2RS	Bearing
35	0901028000	Circlip - φ28
36	3481002101	Blade clutch handle base
37	0102008020	Bolt - M8*20
38	34810023	EMERGENCY STOP
39	34810066	Indicator light
40	34810024	Central information screen
41	34810025	key switch
42	3481002644	Control panel
43	3481003244	Panel lower cover
44	4SC5310010	Throttle cable
45	45A0323010	Big handle sheath
46	3481003449	OPC lever
47	3481003701	Button cap
48	34810038	Return spring
49	3481003901	Remote control switch lever
50	3481004001	Rotary block pressing plate
51	GT68WA36000	Nylon sleeve, link rod
52	GT68WA44000/02	OPC return spring
53	3481004102	Linkage rod
54	GT68WA39000/01	Fixing base, link rod
55	3481004440	Switch button installation base
56	Z61C0300	OPC switch
57	81QZY001	Seat switch
58	BC45TD02000/01	Rotating plate for handle
59	GT68WA12000	Height regulating cable
60	BC45TD21000/02	Spring
61	BC45TD22000/02	Cable core
62	3481004940	Big handle
63	0101012170	Bolt - M12*170
64	0301012000	Flat washer - φ12
65	3481006144	Rotating seat
66	0202012000	Lock nut - M12
67	GT68WB29000/01	Rotation limit plate
68	0304060000	Limit washer - φ60
69	0219060000	Round nut - M60
70	34810063	Bearing and screw
71	0104006050	Screw - M6*50
72	GT68WA20000B1/01	Cable hook
73	0101006012	Bolt - M6*12
74	0104005016	Screw - M5*16
75	SW100A01000004	handle sheath
76	4SC5310020	Throttle grip
77	3481006840	Left protective plate
78	3481007340	Right protective plate
79	0102006040	Bolt - M6*40

Model: WBG6813-TE

Service code:WBG6813TE251124


Chassis



Part2 Chassis Spare parts list		
No.	ID Zboží	Název
1	1601030030	Square tube plug 30*30
2	GT68WB02000/40	Support rod
3	3482011102	Pin φ6.3*50
4	GT68WB31000/44	Right protective plate
5	0101008020	Bolt - M8*20
6	0102006016	Bolt - M6*16
7	0202006000	Lock nut - M6
8	GT68WB05000/44	Front chain bolt
9	GT68WB28000	Hang chain
10	GT68WB04000/44	Front chain mounting plate
11	3482000144	Front chain extension plate
12	GT68WB32000/44	Left protective plate
13	GT68TB03000B1/44	Base plate of blade roll shield
14	GT68WB38000/22	Lower protective plate
15	GT68WB10000/22	Fixed plate for tensioner
16	51A0313010	Nylon bush for rear wheel
17	GT68WB12000/40	Tensioner arm
18	GT68WB33000	Nylon sleeve
19	GT68WB34000/01	Brake arm
20	0201008000	Nut - M8
21	0101008050	Bolt - M8*50
22	GT68WB35000	Brake block
23	GT68WB37000/22	Gasket, brake arm
24	GT68WB36000/22	Brake block pressure plate
25	0401008000	Spring washer - φ8
26	0103005025	Screw - M5*25
27	HA1020	Blade roll belt
28	GT68WB19000B1/44	Belt cover
29	0303008000/02	Big washer - φ8
30	GT68WB14000/02	Tensioner
31	0101006020	Bolt - M6*20
32	GT68WB39000/44	Belt upper pressure plate
33	GT68WB13000/22	Tensioner bush
34	6203-2RS	Bearing
35	GT68WB11000A1/02	Tensioner spring, blade roll
36	GT68WA44000/02	OPC return spring
37	KG12030530	Spring 2
38	GT68WC07000	Pulley
39	1101008030	Key - 8*30
40	0901047000	Circlip - φ47
41	6005-2RS	Bearing
42	0301008000	Flat washer - φ8
43	0101008025	Bolt - M8*25
44	3482000544	Drive shaft sleeve
45	0104004016	Screw - M4*16
46	34820085	Charging socket
47	0202004000	Lock nut - M4
48	34820007	Power off switch
49	3482009344	Chassis
50	0202008000	Lock nut - M8
51	GT68WD14000/44	Fixed base
52	GT68WD13000	Drive shaft
53	1101008040	Key - 8*40
54	34820025	Pulley
55	0301006000	Flat washer - φ6
56	GT68WB01000/44	Protective plate
57	GT68WB26000/01	Fixed blade
58	0202008000	Lock nut - M8
59	34820026	Belt
60	76EJ11010	Cushion
61	3482009644	Front cover plate
62	6203-2RS	Bearing
63	34820083	Spacer bush
64	34820029	Tensioner pulley

Part2 Chassis Spare parts list		
No.	ID Zboží	Název
65	1001015000	Circlip - φ15
66	61902-2RS	Bearing
67	0901028000	Circlip - φ28
68	0101008100	Bolt - M8*100
69	3482003044	Generator tensioning arm
70	34820034	Spring
71	34820035	Power module
72	WB9670004	Relay
73	3482003644	Remote control receiver bracket
74	34820115	Main controller
75	76ED05010	Controller pad
76	3482009444	Controller mounting base
77	76ED06010	Insulation cushion
78	34820114	Slave controller
79	0104004025	Screw - M4*25
80	3482004244	Storage battery rod
81	DP12V12A	Storage battery
82	34820043	Spacer 1
83	34820044	Spacer 2
84	34820045	Spacer 3
85	3482004644	Battery compartmen
86	3482005144	Left protective panel
87	3482005244	Brace
88	5360122010C	Rubber ring
89	0302008000	Big washer - φ8
90	34820056	Rear baffle for battery compartmen
91	3482005744	Right protective plate for battery compartmen
92	3482008704	Locking tab
93	34820088	Air inlet cover plate
94	34820064	Air inlet filter sponge
95	34820089	Air inlet box
96	3482007444	Generator fixing buckle
97	0102010025	Bolt - M10*25
98	34820077	Alternator with pulley
99	0103010050	Bolt - M10*50
100	0202010000	Lock nut - φ10
101	0301010000	Flat washer - φ10
102	3482007844	Outlet
103	0901040000	Circlip - φ40
104	34820082	Aluminum alloy handle
105	0112006016	Screw - M6*16
106	50660001	Screw - M5*30
107	34820090	Small cover plate
108	0102006012	Bolt - M6*12
109	34820091	Handle
110	0101006025	Bolt - M6*25
111	0102006020	Bolt - M6*20
112	0101006010	Bolt - M6*10
113	0104004010	Bolt - M4*10
114	0101008020A	Head thinning type bolt - M8*20
115	34820092	Return spring
116	81EC26000	Sealing strip
117	3472000102	Hang chain
118	34820099	Fan activity door
119	34820100	Fan filter cotton
120	0102006010	Bolt - M6*10
121	34820101	Fan
122	34820102	Fan protective cover
123	50130002	Screw - M4*35
125	3482010444	Fan inlet seat
126	50730001	Screw and flat washer assembly
127	0301004000	Flat washer - φ4
128	34820063	Spring hinge
129	34820108	Insulation cotton

Model: WBGT6813-TE
Service code:WBGT6813TE251124
Main body




Part3 Main body Spare parts list		
No.	ID Zboží	Název
1	0101008025	Bolt - M8*25
2	0401008000	Spring washer - φ8
3	HQB00000100/02	Wheel hub spacer
4	3483000140	Driving wheel
5	0103006080	Screw - M6*80
6	1001025002	Circlip - φ25
7	0901052000	Circlip - φ52
8	6205-2RS	Bearing
9	50570001	Key - 8*7*35
10	34830002	Transmission spline shaft
11	1001058000	Circlip - φ58
12	0103008025	Screw - M8*25
13	3483000340	Half shaft sleeve
14	34830006	Transmission
15	34830043	Motor
16	3483000840	Electromagnetic brake cover
17	34830011	Rubber ring
18	0103005050	Screw - M5*50
19	3483001240	Intermediate casing
20	0102006012	Bolt - M6*12
21	3483001544	Engine belt cover
22	0101012040	Bolt - M12*40
23	0401012000	Spring washer - φ12
24	0301012000	Flat washer - φ12
25	0101010025	Bolt - M10*25
26	0401010000	Spring washer - φ10
27	0301010000	Flat washer - φ10
28	0101010050	Bolt - M10*50
29	0201010000	Nut - M10
30	0102008025	Bolt - M8*25
31	0202008000	Lock nut - M8
32	3483001944	Support plate
33	3483002044	Bottom plate
34	0101008020	Bolt - M8*20
35	0301008000	Flat washer - φ8
36	34830023	Engine belt
37	GT68WB15000	Pulley gasket
38	GT68WE13020 +GT68WE13010	Pulley & Tapered Bushings
39	KN20004HA	Key - 7*45
40	GT68WE21000/22	Silencer cover
41	0103006012	Screw - M6*12
42	0401006000	Spring washer - φ6
43	GT1300	Engine
44	GT68WE10000/02	Engine throttle spring
45	0101010030	Bolt - M10*30
46	3483002440	Engine bracket 2
47	3483002540	Engine bracket 1
48	3483002640	Left bracket
49	0302010000	Big flat washer - φ10
50	0126008025	Shim combination bolt - M8*25
51	3483003140	Right bracket
52	0302008000	Big washer - φ8
53	3483003440	Strengthening plate
54	3483003640	Installation board
55	0103006035	Screw - M6*35
56	0103006025	Screw - M6*25
57	3483004401	Filter cap
58	0202005000	Lock nut - M5
59	0301005000	Flat washer - φ5
60	0101005016	Bolt - M5*16
61	34830045	Dust collector
62	3483004622	Dust collector bracket
63	34830047	Filter box cover
64	3483004822	Filter box gasket
65	34830049	Dust collection cup
66	50820001	Clamp
67	34830050	Intake pipe
68	0102006075	Bolt - M6*75
69	PJ/WXGT003	Air filter component

Model: WBGT6813-TE


Service code:WBGT6813TE251124

Walking part




Part4 Walking part Spare parts list		
No.	ID Zboží	Název
1	0101008020	Bolt - M8*20
2	3484000140	Guide wheel connecting plate
3	GT68TE06000/40	Guide wheel guard
4	1502505207	Sealing ring - 25*52*7
5	1001025002	Circlip - ϕ 25
6	6205-ZZ/T	Bearing
7	GT68TE07000/22	Guide wheel spacer sleeve
8	GT68TE08000/40	Track guide wheel
9	1503005207	Sealing ring - 30*52*7
10	3484000240	Left and right pressure rod
11	3484000440	Chassis
12	0101012030	Bolt - M12*30
13	0101008040	Bolt - M8*40
14	0401008000	Spring washer - ϕ 8
15	0301008000	Flat washer - ϕ 8
16	0101012040	Bolt - M12*40
17	0401012000	Spring washer - ϕ 12
18	0301012000	Flat washer - ϕ 12
19	2501006000A	Oil cup - M6
20	GT68TE11000/40	Fixed seat pressure plate
21	GT68TE12000	Track spindle upper seat
22	GT68TE13000	Track spindle lower seat
23	3484001840	Chassis rear axle
24	0201014000	Nut - M14
25	0101014180	Bolt - M14*180
26	3484001140	Pedal bracket
27	34840014	Bolt
28	0201008000	Nut - M8
29	3484001540	Activity board
30	0101008060	Bolt - M8*60
31	0202008000	Lock nut - M8
32	GT68TE09000	Track
33	0202012000	Lock nut - M12
34	0102006012	Bolt - M6*12
35	GT68TE20000/40	Tail guard
36	GT68TE23000	Hydraulic support rod
37	GT68TE19000/40	Pedal
38	0303008000/02	Big washer - ϕ 8
39	3475000902	Grass guard bowl

Model: WBGT6813-TE
Service code:WBGT6813TE251124
Swing blade roller




Part5 Swing blade roller Spare parts list		
No.	ID Zboží	Název
1	UCFC206	Bearing
2	0101010045	Bolt - M10*45
3	0401010000	Spring washer - ϕ 10
4	0301010000	Flat washer - ϕ 10
5	GT68WC05000/22	Mounting disc for blade roll
6	GT68WC01000/22	Bearing cover
7	GT68WC02000/01	Blade
8	GT68WC03000	Blade bolt
9	0201010000DD	Nut - M10
10	GT68WC04000/22	Blade roll
11	0101010050	Bolt - M10*50
12	GT68WC07000	Pulley
13	1101008030	Key - 8*30
14	PJ/WXGT001	Blade Repair Kit

Model: WBGT6813-TE
Service code:WBGT6813TE251124
Front wheel bracket



Part6 Front wheel bracket Spare parts list		
No.	ID Zboží	Název
1	3486001402	Dust cover
2	0202010000	Lock nut - M10
3	0302010000	Big flat washer - ϕ 10
4	30202	Bearing
5	32004	Bearing
6	34860008	Oil seal
7	0301012000	Flat washer - ϕ 12
8	GT68WD05000	Universal wheel
9	0202012000	Lock nut - M12
10	3486000240	Universal wheel bracket
11	0101012095	Bolt - M12*95
12	0102006016	Bolt - M6*16
13	GT68WD20000A1/40	Shadoof
14	0103012050	Bolt - M12*50
15	0401012000	Spring washer - ϕ 12
16	3486000440	Front wheel bracket
17	51A0313010	Nylon bush for rear wheel
18	GT68WD06000/22	Bush for front wheel bracket
19	GT68WD12000/37	Slope pointer
20	0102006012	Bolt - M6*12
21	0101010055	Bolt - M10*55
22	GT68WD07000/44	Fixed rod
23	0103006016/12P9	Bolt - M6*16
24	3474000102	Spacer
25	GT68WD08000/44	Rocker screw
26	48R0113010	Nylon bush
27	0103008090	Screw - M8*90
28	GT68WD10000	Rocker handle
29	0201008000	Nut - M8
30	GT68WD09000A1/44	Rocker
31	0701005025	Pin - ϕ 5*25
32	0301016000	Flat washer - ϕ 16
33	0301010000	Flat washer - ϕ 10
34	2501006000A	Oil cup - M6

Model: WBGT6813-TE
Service code:WBGT6813TE251124
Wiring loom



Part7 Wiring loom Spare parts list		
No.	ID Zboží	Název
1	34870006	Engine kill wire
2	34810001	Turn controlling switch
3	34810008	Speed regulating switch
4	34810066	Indicator light
5	34810023	Emergency stop button
6	34810024	Central information screen
7	34810025	Key switch
8	81QZY001	Remote control switch
9	34870012	Remote control switch wire
10	Z61C0300	OPC switch
11	34870002	Main wire harness
12	34830043	Motor
13	34820077	Alternator with pulley
14	34870013	Power off switch 1A connection wire
15	34870008	Battery output wire
16	34820035	Power module
17	DP12V12A	Battery
18	34870009	Battery connection wire
19	WB9670004	Relay
20	34870011	Alternator positive wire
21	34870007	Controller positive wire
22	34820085	Charging socket
23	34820115	Main controller
24	34820114	Slave controller
25	34870010	Controller negative wire
26	34870016	Alternator excitation signal wire
27	34870014	Power off switch 1B connection wire
28	34870015	Power off switch 2 connection wire
29	34820007	Power off switch
30	WB9681005	Fuse 150A
31	34870017	Fuse tube 10A 5*20mm
32	WB9650012	Protective sheath 14*8
33	WB9650011	Protective sheath 14*8
34	WB9650008	Protective sheath 12*22
35	34820101	Fan
36	76EK09010	USDopean standard charging cable
37	76EK03010	American standard charging cable
38	76EK06010	British standard charging cable
39	76EK07010	Great South Africa standard charging cable
40	76EK08010	Australian standard charging cable
41	68EQ01000	Charger
42	76LDH002-01	Key
43	34870018	Three-post junction box assembly
43,1	0104004016	Screw - M4*16
43,2	34870019	Upper cover for junction box
43,3	0202005000	Nylon lock nut - M5
43,4	34870020	Lower cover for junction box